Disassembling Sony Vaio PCG-F360 Clock Battery

Written By: ahintz



INTRODUCTION

This computer comes with a separate battery to power its clock. This battery can be easily accessed on the bottom of the computer.

TOOLS:

- Phillips #00 Screwdriver (1)

Step 1 — Clock Battery





- Remove the two clock battery screws with the screwdriver.

Step 2





- Carefully pop the button battery out of its holder.
- Replace the battery with another of identical type.
- Replace the battery cover and screws.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-04 04:25:35 PM.